



# C9150-5

## Setup Instructions

for Automatic and Grand  
Revolving Doors



9.310d1



## OVERVIEW OF H916 SETUP INSTRUCTIONS FOR C9150-5 CONTROL

This manual contains very detailed instructions for successful setup and adjustment of the C9150 control. All wiring and initial run of the door can be accomplished by following the directions in sections 1 through 12. The remainder of the manual contains reference material for options and features that may not be required in all applications.

The concise table of contents will be useful to find the pertinent section of the instructions required for each application. The C9150 control offers greater flexibility than any revolver control offered before. The operation of the door can now be changed with the keyswitch or remote control. Previously, these functions were changed by changing the firmware (EPROM chip). The C9150 has expansion slots for additional input, output or specialized cards that can be added to expand the capabilities of this versatile control.

### THIS MANUAL CONTAINS THE FOLLOWING SECTIONS:

**BASIC SETUP** A step by step outline of the wiring, setup and testing of each part to be installed such & **TESTING:** as motor and, optional, brake, sensors, nosing etc.

The sections below give detailed instructions on setting up the functions that are accessed by the keyswitch, remote control and the control itself. The control may be password protected if desired.

**DIAGNOSTICS:** Used to set up and maintain the revolving door such as...

- Calculating the speed of the door in RPM
- Testing the voice module.
- Global relearn which sets the safety sensitivity to a base line level.
- Checking motor voltage and current.

**MODE:** Defines how the door will be used

- Park stops all activating signals so the door will stop (and lock).
- Full automatic
- Exit only - door is not locked - but only responds to interior activation devices.
- Continuous run - after activation expires, the door will continue to run at reduced speed until activation signal is received.

**PARAMETERS:** Cover such functions as...

- Door speed
- Time delays
- Reaction to, and force required for safety stops.
- Adjust time delays, safety stops before idle and many other variables.

### INSTRUCTIONS TO INSTALLER

- This door is to be installed by an experienced installer, trained by Horton Automatics.
- To ensure safe and proper operation, the door must be installed and adjusted to conform to Horton Automatics recommendations and all code requirements.
- If there are any questions about these instructions, call Horton Automatics Technical Service (1-800-531-3111).

### INFORMATION TO BE PROVIDED BY THE DISTRIBUTOR TO THE OWNER

- After installation, instruct the owner on the safe operation of the door.
- Present the Owners Manual M900 (Automatic) and explain how to perform the daily safety check.
- Location of power on / off switch.
- Necessary warnings not covered in these general instructions.
- Date equipment shipped from Horton Automatics.
- Date equipment placed in service.
- Horton Automatics' work order number for warranty reference.
- Equipment type.
- Accessories included.
- Phone number of local distributor to call regarding problems or request for service.
- Give caution to owner: If a potentially hazardous situation is suspected, the door should be taken out of automatic service until a professional inspection is made and the problem is corrected.

### GENERAL REQUIREMENTS

- Power:(Switchable on the control)120V or 240V, 50 / 60 Hz 15A service to each unit.
- For remote switch locations, routing of low voltage class II wiring to the operator controls will be required.
- Remote switch locations should be predetermined and wired before installation begins.

# CONTENTS

## REFERENCE (for basic setup)

- A. C9150 Control and power supply.....H916.1
- B. Control connections.....H916.2

## BASIC SETUP

- 1. Basic setup (wiring motor, brake and encoder).....H916.3
- 2. Basic setup (wiring reference switch).....H916.4
- 3. Basic setup (wiring slip ring assembly and magnetic breakout).....H916.5
- 4. Basic setup (wiring emergency stop switch, fire alarm, LCP and key switch). H916.6

## TESTING SETUP

- 5. Basic setup (introduction to diagnostics).....H916.7
- 6. Basic setup (checking motor and brake current).....H916.8
- 7. Basic setup (setup run).....H916.9
- 8. Basic setup (setup run).....H916.10

## BASIC SETUP

- 9. Basic setup (wiring entry guard, speakers and slow speed switches).....H916.11
- 10. Basic setup (wiring motion detectors and lights).....H916.12
- 11. Basic setup (nosing wiring).....H916.13

## TESTING SETUP

- 12. Basic setup (testing) motion detectors .....H916.14

## REFERENCE CHARTS (for setup)

### DIAGNOSTICS

- 13. Diagnostics 1 (check power supply).....H916.15
- 13. Diagnostics 2 (check door speed).....H916.15
- 14. Diagnostics 3 (check motor voltage and current).....H916.16
- 14. Diagnostics 4 (check brake voltage and current).....H916.16
- 14. Diagnostics 5 (check brake voltage and current).....H916.16
- 15. Diagnostics 6 (encoder test).....H916.17
- 15. Diagnostics 7 (testing inputs).....H916.17
- 16. Diagnostics 8 (voice).....H916.18
- 16. Diagnostics 9 (check low voltage DC supply).....H916.18
- 16. Diagnostics 10 thru 13 (reserved).....H916.19
- 17. Diagnostics 14 (need help).....H916.19
- 17. Diagnostics 15 (learn safety limits).....H916.19
- 18. Diagnostics 16 (complete setup).....H916.20

### MODES

- 19. Door modes (modes 0 thru 3 ) .....H916.21
- 20. Door operating modes (using the infra-red remote).....H916.22


### PARAMETERS

- 21. Parameter chart 1 (Speed •normal •reduced •reverse •reserved).....H916.23
- 22. Parameter chart 2 (safety sensing & safety stop time).....H916.24
- 23. Parameter chart 3 (normal speed dwell•reduced speed dwell•storm sw duration)....H916.25
- 24. Parameter chart 4 (idle mode timeout • Park-N-Lock dwell• help sw timeout).....H916.26
- 25. Parameter chart 5 (reserved time • speed up warning • safety stops to idle).....H916.27
- 26. Parameter chart 6 (entry guard offset • network address • reserved).....H916.28
- 27. Parameter chart 7 (K2,K3 & K4 mapping • reserved).....H916.29
- 28. Parameter chart 8 (remote mode - hardwired ).....H916.30
- 29. Parameter chart 9 (remote mode slct • Push-N-Go • core brake installed ).....H916.31
- 30. Parameter chart 10 (storm switch only • parallel core wiring • reserved).....H916.32
- 31. Parameter chart 11 (wing sensors 3 thru 8).....H916.33


### APPENDIX

- 32. Parameter quick reference chart .....H916.34
- 33. Diagnostics quick reference chart .....H916.35
- 34. Error codes.....H916.35
- 35. Connecting sensors to the C9150 control for Automatic Revolvers .....H916.36
- 36. Connecting sensors to the C9150 control for Grand Revolvers.....H916.37

## A. C9150 CONTROL AND POWER SUPPLY



## B. CONTROL CONNECTIONS



## 1. BASIC SETUP(wiring motor,brake and encoder)

### NOTE:



If the door runs backwards, when tested in section 6;

•Check that the gear drive is not upside down. "Top" should be stamped on the "up" side. The gear drive may be turned over to the correct position **OR...**

•Reverse the black and white leads at the CN 1 connection. If an encoder error occurs, reverse leads 2 and 3 on the encoder.

### "TOP"


Should be stamped on "up" side




H916.3

**Brake, motor and encoder connections are factory installed. Illustrations are for reference only**


Motor (Red) → Wht → To CN1 on the power supply board.  
Motor (Blk) → Blk →




All lace connections will pass through the strain relief opening. Tighten clamp when all wires are in place




**3rd Step**  
Encoder connection at the control board



**1st Step**  
! Check power supply for proper voltage setting  
115 V → 230 V




**2nd Step**  
Brake and motor connection



**NOTE:  
DO NOT PLUG IN UNTIL LATER (SECTION 6)**

Use a screw driver in the slot to adjust slide switch  
(Switch is factory set at 120VAC)

## 2. BASIC SETUP (wiring reference switch)




H916.4


### INDICATOR SETUP FOR 3-WING (Door will stop in "Y" position)



### INDICATOR SETUP FOR 4-WING (Door will stop in "X" position)




Connect to  
C9150 control




**Last Step**  
**NOTE:** After setup, SLOWLY rotate door and watch for proper alignment and no contact at all indicators.  
Turn breaker on and watch for the LED, D2, (see above) to light at each quarter point position

### 3. BASIC SETUP (wiring the slip ring assembly and magnetic breakout or storm lock)

C9150 CONTROL





#### 4. BASIC SETUP (wiring emergency stop switch, fire alarm,LCP and key switch)



## 5. BASIC SETUP (introduction to diagnostics)

Before proceeding 3 diagnostics should be performed: spot check of motor and brake function to insure proper operation, and then a setup run.  
The following is an outline for performing these diagnostics.

These diagnostics may be performed using the IR control and the LCP (Local Control Panel) or the MCP (Main Control Panel).  
The MCP will provide more information and can be used for reference even when using the remote / LCP.



### Accessing the diagnostics from the infrared control.


•Point the IR remote at the LCP and press unlock

•The red LED on the LCP display will flash - indicating the signal is being received.

•If the control was previously locked with a password, the LCP will show to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.


•If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as

- Press "SU" diagnostics will appear




### Accessing the diagnostics from the control itself.

•Press and hold the DOWN button while briefly pressing RESET.



•If the control is locked with a password it must be unlocked with the IR remote.

•Diagnostics/Setup will display



GO TO NEXT PAGE TO CHECK MOTOR AND BRAKE CURRENT

## 6. BASIC SETUP (checking motor and brake current)


**PLUG IN CN1(motor and brake connection) as shown in basic setup.**  
If the door runs backwards see section 1.

Accessing the diagnostics from the infrared control.

Accessing the diagnostics from the control itself.

### CAUTION: DOOR WILL MOVE AT SPEED SET IN PARAMETER 1 (default 60 volts)

The order in which the diagnostics are arranged



GO TO NEXT PAGE

## 7. BASIC SETUP (setup run)



Before installing any additional devices, a setup run should be performed. The setup run sets factory default settings to all parameters, zeros all counters and sets safety sensitivity settings.

### Accessing the diagnostics from the infrared control.



#### COMPLETE SETUP

**CAUTION:** The door will move on its own when this routine is initiated! use extreme caution to avoid entrapment.  
This diagnostic allows a complete control setup to be performed. This diagnostic can be the most **DESTRUCTIVE** if it is performed accidentally.  
It should always be performed when initially installing a door and **never** be performed without good reason otherwise.


- Press 16 or "+" up "-" down  
Until 16 is displayed
- Press "?"




- Confirmation will be requested.
- To cancel the setup, press the "\_" key.
- If door is a 3 wing press +  
•If door is a 4 wing press -
- Press the "+" key again to perform the diagnostic.




- Press UP till  
16 is displayed




- Diagnostics/Setup  
Do Complete Setup?



- Setup:are you sure?  
Yes:Up/+ No:Down/-
- NOTE: If it's a 4-wing  
press down / -



- Press the UP button again to perform the diagnostic.





- Door will move

H916.9



16

#### PULSES PER QUADRANT

•The door rotates through 3 or 4 quarterpoints and counts the total encoder pulses to determine how many pulses are present in each quadrant.



- To cancel the setup, press the DOWN button.





- Seeking ref ..1 thru 4

- Peak I = 0.48

#### REDUCED SPEED CURRENT

•The door rotates through 3 or 4 quarterpoints at reduced speed to determine the maximum current



## 8. BASIC SETUP (setup run)

Accessing the diagnostics from the infrared control.


### COMPLETE SETUP (CONT')

#### STARTUP CURRENT

The door rotates through one quadrant

- After the door stops rotating, press the lock key


16  
CONT



THIS CONCLUDES THE BASIC SETUP RUN

H916.10

**NOTE:**  
Disconnect CN1 (motor & brake) so that the auxiliary equipment can be connected and tested without the danger of the door rotating and causing injury or someone becoming entrapped by the brake (lock).



GO TO THE NEXT PAGE TO COMPLETE THE WIRING



## 9. BASIC SETUP (wiring Entry Guard™, speakers and slow switches)

### TURN BREAKER OFF BEFORE CONNECTING WIRING

Improper adjustment of contrast can cause the display to look blank

**Contrast**  
Adjust volume and contrast to 9:00


**Limit**  
Adjust limit fully counter clockwise




C9980  
Speaker

**1st Step**  
Connect the speaker and set the Limit, Contrast and Volume as shown.  
**Go to diagnostics 8 to test voices.**

CN10



CN9




Exit slow switch  
Red 1  
Blk 2





Exit slow switch  
Red 1  
Blk 2

Entr. slow switch



E6222-1  
Switch harness  
(Routed from the control)

Exit slow switch  
(See detail)




Located 36"(914) to 48"(1219) from finished floor.

**Slow speed switch mounting**  
• Remove the face plate and switch.  
• Drill a 1/4" hole where required for the wires to pass through.  
• Crimp wire connectors onto wires.  
• Position switch box as required drill and mount with (2) #10 sheet metal screws

## 10. BASIC SETUP (wiring motion detectors and lights)

### TURN BREAKER OFF BEFORE CONNECTING WIRING

Route all wiring through  
the strain relief




C9150 control

### TEST THE MOTECs

Turn on the power.  
Have someone pass through each  
of the detection zones.  
D12 will light for the entry and  
D13 will light for the exit


### ADJUST THE MOTEC

with the remote as per EAGLE instructions.  
NOTE: Place remote in "others" position to  
adjust the motec (see Sect. 5).  
Move the switch back for control adjustments.



### CONTROLLING LIGHTS FROM THE KEYSWITCH


(Turn the power on)



Move the keyswitch to the right  
and HOLD to turn lights on.  
Return to center position.



Move the keyswitch to the right  
again and HOLD to turn lights off.  
Return to center position.



**C9553**  
4-plex with cord and plug  
Locate 4 plex plug in the canopy  
and plug lights into it.

## 11. BASIC SETUP (nosing wiring)


### 5th Step TEST THE NOSINGS

- Turn the power on.
- Push each leading nosing LED D20 will come on.
- Push each trailing nosing LED D22 will come on

**TURN BREAKER OFF  
BEFORE CONNECTING WIRING**

**TRAILING  
NOSINGS  
LEADING  
NOSINGS**

D22  
D20




**1st Step**  
Interface board is supplied with the control accessories. Mount to the gear drive support tubes with #6 SMS support tubes with #6 SMS (drill 3/32" pilot hole)

**2nd Step**  
Route safety edge wiring to control nosing interface board mounted on geartrain support tubes

Nosing wires should be pulled into the canopy during drum and canopy assembly


**3rd Step**  
Make connections at nosing interface board.



LOCK MONITOR  
SWITCH (optional)  
ONLY ON GRANDS

HELP SWITCHES  
(optional)  
To CN5 see Sect 4

**\* NOTE:**  
**DO NOT CONNECT TRAILING NOSING-  
ONLY THE LOCK MONITOR SWITCH, IF  
EQUIPED.**  
(Trailing nosing is only connected on security doors.)




## 12. BASIC SETUP (testing)

The following tests are designed to check all inputs and outputs. The tests are conducted in mode 1. Plug in CN1 (motor and brake) and turn the **breaker on**.

### MOTION DETECTOR ACTIVATION (mode 1)

(If MCP does not read mode 1 ready... see SEC. 19)



## 13. DIAGNOSTICS CHART 1

### SEE SECTION 5 FOR INTRODUCTION TO CONTROL SETUP

#### Accessing the diagnostics from the infrared control.

- The door must be inactive (in standby condition)
- Point the IR remote at the LCP and press unlock
- The red LED on the LCP display will flash - indicating the signal is being received.
- If the control was previously locked with a password, the LCP will show to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.
- If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as

•Press "SU" diagnostics will appear

The order in which the diagnostics are arranged

1 1

2

3 1

4 1

5 2

6 1

7 1

8 1

9 1

10 ---


11 ---

12 ---

13 2

#### Accessing the diagnostics from the control itself.

- Press and hold the DOWN button while briefly pressing RESET.



- The version number will display
- If the control is locked with a password it must be unlocked with the IR remote.

- Diagnostics/Setup will display
- Release the DOWN button

To return to the main diagnostics menu, press the "SU" button on the remote. Press the LOCK button, on the remote, or hold the DOWN button and briefly push the RESET on the control to exit all diagnostics and restore normal door operation.

CHECK POWER SUPPLY

•After a few seconds diagnostic 1 will display or...  
•Press 1 or "+" up "-" down

•Press "?"

•Displays DC voltage output of the power supply to operate the motor and the core brake. Voltage will fluctuate with changes in the incoming voltage. A typical value is 111 to 114 VDC


CHECK DOOR SPEED

•Press 2 or "+" up "-" down

•Press "?"

•Ramps the motor up to normal speed and displays it in RPM.

2  
•Using the + and - keys on the IR remote the motor voltage may be changed in small steps (temporarily) to determine the motor voltage required for a desired speed. The actual voltage is changed in parameters 1 and 2.



To choose this speed for Normal --- Press 1  
Reduced - Press 2  
Quarter point ----- Press 3

If the door speed is changed, re-do diagnostic 15  
(Reset safety sensitivity levels)



## 14. DIAGNOSTICS CHART 2

### Accessing the diagnostics from the infrared control.

#### CHECK MOTOR VOLTAGE AND CURRENT

- Press 3 or "+" up "-" down
- Press "?"
- Displays motor amperage
- Useful for hunting mechanical binds
- Checking overall performance of the doors mechanics.


3



### Accessing the diagnostics from the control itself.

#### CHECK MOTOR VOLTAGE AND CURRENT


- \*Diagnostics/Setup Check motor(LCP=I)?
- Press UP till 3 is reached
- Press SET
- Press UP DOWN RESET
- Displays motor voltage and amperage




#### CHECK BRAKE VOLTAGE (If present)

- (LCP displays voltage)
- Press 4 or "+" up "-" down
- Press "?"
- Engages the core brake and displays the voltage.
- Voltage will fluctuate with line voltage changes.
- A value of 90 to 105VDC is typical.
- Verify that the brake engages mechanically and properly locks the door.
- Checks the brake control subsections of the control.

4




- \*Diagnostics/Setup Check brake(LCP=V)?
- Press UP till 4 is reached
- Press SET
- Press UP DOWN RESET
- Displays brake voltage and amperage



#### CHECK BRAKE VOLTAGE (If present)

- (LCP displays current)
- Press 5 or "+" up "-" down
- Press "?"
- Brake current is displayed.
- Current is typically in the 200ma range

5



- \*Diagnostics/Setup Check brake(LCP=I)?
- Press UP till 5 is reached
- Press SET
- Press UP DOWN RESET
- Brake current and voltage are displayed



15. DIAGNOSTICS CHART 3

Assessing the diagnostics from the infrared control

## Assessing the diagnostics from the control itself

ENCODER TEST

- Press 6 or "+" up "down  
Press "?"

- The encoder count is displayed up to 999. If the count exceeds 999 the LCP displays ----. The encoder count should increase smoothly as the door is pushed.

**MANUAL ENCODER TEST**  
If the door is pushed backwards the encoder will count from 0 to 65535 on the encoder. To manually test the reverse operation of the encoder, push the door forward. To manually test the reverse operation of the encoder.

**POWER ENCODER TEST**  
The encoder may also be checked by pressing the 1 key on the IR remote. The door will run forward at a slow speed -the speed may be changed up or down by using the + and - buttons on the IR remote. Pressing the 2 button will run the door in reverse.  
Press zero on the IR remote to return to manual encoder testing.

TESTING INPUTS

- Digitized by srujanika@gmail.com

- All the codes of all active inputs are displayed as they are polled.

10

- |     |                             |
|-----|-----------------------------|
| LCD | Reference switch on         |
| 1   | Lock monitor switch on      |
| 2   | Leading safety nosings on   |
| 3   | Card contact on (Reserved)  |
| 4   | Card contact on (Reserved)  |
| 5   | Exit slow switch on         |
| 6   | Entrance slow switch on     |
| 7   | Exit motion detector on     |
| 8   | Entrance motion detector on |
| 9   | Keypad SET on               |
| 10  | Keypad SEL on               |
| 11  | PV-3 reserve on             |
| 12  | AUX B/Help switch on        |
| 13  | AUX A mode set on           |
| 14  | Fire contact on             |
| 15  | Emergency stop contact on   |
| 16  | PZ-7 reserved on            |
| 17  | DIP1 on                     |
| 18  | DIP2 on                     |
| 19  | DIP3 on                     |
| 20  |                             |

Assessing the diagnostics from the control itself

לְמִזְרָחַ וּלְמִזְרָחַ לְמִזְרָחַ וּלְמִזְרָחַ

- Press UP till 6 is reached

- Encoder count is displayed up

0

- 7 is reached  
SET  
UP  DOWN  RESET

- Any active inputs (card reader, motion detector, etc.) are displayed in text form showing exactly which inputs are active

- NOTE: These codes may appear if card is NOT installed in the system. In this case the codes are meaningless.

## 16. DIAGNOSTICS CHART 4

### Accessing the diagnostics from the infrared control. VOICE

- Press 8 or "+" up "-" down
- Press "?"
- Displays V.1, V.2, V.3 & V.4  
Use the "+" and "-" keys to select any of the voices stored in the control's speech memory.  
Use the "?" key to play the selection.  
Voices may be played from the IR control but not recorded
- To record a new message:  
Select the message to be replaced  
Hold the SET button until REC appears. Hold the REC button and speak directly into the microphone. The total length of each message cannot exceed 5 seconds.
- CAUTION:** Pressing the REC button will completely erase the previous message.
- The REC button is disabled at all times except when this setup routine is run.
- The factory default messages are:  
Voice 1 "Caution door speed will increase"  
Voice 2 "Please step forward"  
Voice 3 "Please exit - door will lock" (For Park-N-Lock)  
Voice 4 Door in slow speed - Do not push

8

### Accessing the diagnostics from the control itself.


- \*Diagnostics/Setup Play/Setup Voices?  

















- Press UP till 6 is reached  












- Press SET  





















- The message number will be displayed.  
Use the UP and DOWN keys to select a voice message.  


















- Use the SET key to play that message.  

































- Press and hold the REC key  
•Speak directly into the microphone
- Message 1?  
Up/Down/Set  




















- Message 1?  
Up/Down/Set  




















- Rec is displayed
- Message 1?  
Up/Down/Set  















- Actual voltage is displayed

### CHECK LOW VOLTAGE DC SUPPLY

- Press 9 or "+" up "-" down
- Press "?"
- Low voltage power supply value is displayed.  
A typical value is 24 to 25 volts.

9



### RESERVED

- 10 thru 13 are reserved diagnostics
- Press 10 thru 13 or "+" up "-" down  
The number of each will display on the LCP

10

11

12

13

## 17. DIAGNOSTICS CHART 5

### Accessing the diagnostics from the infrared control. FINDING SAFETY SENSORS

When this diagnostic is requested, the control looks for wing sensors connected to the serial data port via the slip ring assembly.

- Press 14 or "+" up "-" down

A list is generated showing if the sensor is present or not.

- Use "+" up "-" down to view the entire list

- When all sensors that are installed are properly shown on the display press ?

From this point on, any sensors that were found FSS diagnostics will be acted on by the control and will either stop or slow the door depending on the setting s of Parameter 93 thru 99.

All sensors should be connected using fail-safe wiring (normally closed contacts, open contact = sensor active).

### Accessing the diagnostics from the control itself.

When this diagnostic is requested, the control looks for wing sensors connected to the serial data port via the slip ring assembly.

- \*Diagnostics/Setup  
Finding safety sensors

•Press UP till 14 is reached

SET UP DOWN RESET

OR

•Use the UP / DOWN keys to view the entire list

•Press set to save the list

"Sensor list saved"

**F55**

**!14**

**!1n**

**555**

**momentary display**

**55L**

**0.56**

### LEARN SAFETY LIMITS

#### CAUTION: The door will move on its own when these routines (diagnostic 15 & 16) is initiated! Use extreme caution to avoid entrapment.

The C9150 control can measure the current draw of the door's motor and automatically set the "safety sensitivity" settings to the suggested values for the installation. These parameters are automatically set when a complete control setup is performed. An adjustment in motor speed will require changing these settings. Instead of hand adjusting them, this routine will force the control to update the settings. Adjust the safety limits to individual requirements.

- Press 15 or "+" up "-" down

•Press "?"

- This diagnostic will run 4 routines and store the highest current draw of each one.

- The highest current value for each routine is displayed on the LCP

•The door will proceed through 4 quarterpoints at:

Normal speed forward  
then  
Reduced speed forward

Parameter 6 Safety Sens - Fwd  
and  
Parameter 7, Safety Sens - Reduced

The highest running current will be stored and display and the parameter set at 200% of this value.

Parameter 8, Safety Sens - QtPt

- The door will proceed forward to the:

Next quarterpoint

- The display will return to the main diagnostic menu.

If the door speed is changed, re-do diagnostic 15 (reset safety sensitivity levels)

H916.19

- \*Diagnostics/Setup  
Learn Safety Limits?

•Press UP till 15 is reached

SET UP DOWN RESET

•Press SET

UP DOWN RESET


•Press set to save the list

"Seeking ref = 4"

**15**

**55L**

**0.56**



- Forward at normal speed  
then reduced speed

- Parameter 10 Safety Sens - Startup  
The highest startup current will be stored and displayed and the parameter set at 200% of this value.

**NOTE:**  
Factory defaults are set for testing and may not be suitable for individual conditions.  
See parameters 6 thru 10 for manual setup of safety sensitivity

## 18. DIAGNOSTICS CHART 6

Accessing the diagnostics from the infrared control.

### COMPLETE SETUP

**CAUTION:** The door will move on its own when this routine is initiated! use extreme caution to avoid entrapment.

This diagnostics allows a complete control setup to be performed. This diagnostic can be the most **DESTRUCTIVE** if it is performed accidentally. All parameters will be set to factory default. This diagnostic should always be performed when initially installing a door and **never** be performed without good reason otherwise.

- Press 16 or "+" up "-" down
- Press "?"
- Confirmation will be requested.
- To CANCEL the setup, press the ":" key.
- Press the "+" key again to perform the diagnostic.
- If door is a 3 wing press +
- If door is a 4 wing press -
- Press the "+" key again to perform the diagnostic.



16

The setup restores factory default settings to all parameters.

- It rotates the door through 3 or 4 quarterpoints and counts the total encoder pulses to determine how many pulses are present in each door quadrant.
- Finally, the door is rotated through additional quadrants to automatically set safety limits (see diagnostic 15).

Once all the above is complete, the display is returned to the main diagnostic menu.

- Press the lock key




Accessing the diagnostics from the main control panel.

H916.20

**NOTE:**  
Factory defaults are set for testing and may not be suitable for individual conditions. Some parameters may require manual adjustment.


- Press the **RESET** button.





20. USING THE IR REMOTE

H916.22



## 21. PARAMETER CHART 1

.The door must be inactive (in standby condition)

### Accessing the parameters from the infrared control.

- Point the IR remote at the LCP and press unlock 
- The red LED on the LCP display will flash - indicating the signal is being received.
- If the control was previously locked with a password, the LCP will show **Unl** to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.
- If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as **P.!**
- Parameter will appear

To view or adjust the setting of a parameter, briefly press the "?"

- Parameter value will appear

Press the "+" or "-" key to change a yes or no or numeric parameter. Numeric values may be set with the number keys 0..9

• Press the lock key to return to normal operation

The values shown for parameters in the following charts are default values that are set when the complete control setup is performed. Do not adjust control parameters without having a desired goal in mind.

### Speed - (1)normal / (2)reduced / (3)Qt pt / (4&5) reserved

Parameters 1 thru 3 set the operating speed of the door during normal, reduced, and qtpt run conditions (4 & 5 are reserved). The selected value directly equals the motor voltage. Acceptable values are 25 and up - the door will not turn below 25 volts. Horton suggest a run speed of 4 RPM.

**CAUTION:** Higher settings increase the possibility of serious injury to pedestrians. These parameters should be set at the lowest acceptable speed.

### Accessing parameters from the infrared control.

1      Press "+" up "-" down or the number keys to locate the desired parameter

2      Press "?" to view the parameter

3      Press "+" up "-" down or the number keys to change the value

4      **P.2**      Speed - reduced Parameter 2: 45


5      **P.3**      Speed - Qt pt Parameter 3: 45

**P.4**      Speed - (reserved 1) Parameter 4: 0

**P.5**      Speed - (reserved 2) Parameter 5: 0

### Accessing the parameters from the control itself.

- Press and hold the **SET** button while briefly pressing **UP**.
- Unlock will display
- Release the set button



- The parameter name, number and current setting will appear.

- The parameter value is changed with the **UP** and **DOWN** buttons.
- Press **RESET** to return to normal operation

**NOTE:**  
After a few seconds with no entry the display will switch back to the parameter number. The new value will be stored in memory

The values shown for parameters in the following charts are default values that are set when the complete control setup is performed. In most cases these values will be acceptable for ideal door performance. Do not adjust control parameters without having a desired goal in mind.

### Accessing parameters from the main control panel.

Parameter 1      **P.!**      Factory default is 4 RPM

Speed - normal Parameter 1: 60

Speed - reduced Parameter 2: 45

Speed - Qt pt Parameter 3: 45

Speed - (reserved 1) Parameter 4: 0

Speed - (reserved 2) Parameter 5: 0

## 22. PARAMETER CHART 2

### Safety sens - forward / reduced / Qt pt / startup

Parameters 6 thru 8 and 10 (parameter 9 is reserved) set the sensitivity to increased motor current caused by obstructions to the doors. The default values are set at 15 - this means that a safety stop will occur if the motor current exceeds 1.5amps. During the control setup routine these values will be "tweaked" to 200% of the highest current found. For example: if during the forward run the maximum motor current detected was 1.2 amps, parameter 6 will be set at a value of 24 (2.4 amps).

Decreasing these values will provide greater safety at the risk of additional nuisance stops.

#### Accessing parameters from the infrared control.

6	<b>P.6</b>	Safety Sens - Normal Parameter 6: 15
7	<b>!5</b>	Safety Sens - Normal New Value? 15
8	<b>P.7</b>	Safety Sens - Reduced Parameter 7: 15
9	<b>P.8</b>	Safety Sens - Qpt Parameter 8: 15
10	<b>P.9</b>	Safety Sens - reserved Parameter 9: 15
	<b>P.10</b>	Safety Sens - Startup Parameter 10: 15

**NOTE:** If parameter 6, 7 or 8 is automatically set to 20 or more by the setup routine, or parameter 10 was set at 45 or more, excessive motor current is being drawn which may indicate a mechanical problem or a bind in the door.

\*All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.

#### Safety stop time

11	<b>P.11</b>	Safety stop Time Parameter 11: 35
	<b>35</b>	Safety stop time New Value ? 35
	<b>30</b>	Safety stop time Parameter 11: 30

#### Accessing parameters from the main control panel.

•Press "+" up "-" down or the number keys to locate the desired parameter	<b>P.6</b>	Safety Sens - Normal Parameter 6: 15
•Press "?" to view the parameter	<b>!5</b>	Safety Sens - Normal New Value? 15
•Press "+" up "-" down or the number keys to change the value	<b>P.7</b>	Safety Sens - Reduced Parameter 7: 15
	<b>P.8</b>	Safety Sens - Qpt Parameter 8: 15
Reserved parameter	<b>P.9</b>	Safety Sens - reserved Parameter 9: 15
	<b>P.10</b>	Safety Sens - Startup Parameter 10: 15

•Press UP or DOWN to scroll to view the parameter.

•Press UP or DOWN to change the setting.

•Press UP or DOWN to scroll to view the parameter.

•Press UP or DOWN to change the setting.

#### Accessing parameters from the main control panel.

•Press UP or DOWN to scroll to view the parameter.	<b>P.6</b>	Safety Sens - Normal Parameter 6: 15
•Press UP or DOWN to scroll to view the parameter.	<b>!5</b>	Safety Sens - Normal New Value? 15
•Press UP or DOWN to scroll to view the parameter.	<b>P.7</b>	Safety Sens - Reduced Parameter 7: 15
•Press UP or DOWN to scroll to view the parameter.	<b>P.8</b>	Safety Sens - Qpt Parameter 8: 15

•Press UP or DOWN to scroll to view the parameter.

•Press UP or DOWN to scroll to view the parameter.

•Press UP or DOWN to scroll to view the parameter.

•Press UP or DOWN to scroll to view the parameter.	<b>P.6</b>	Safety Sens - Normal Parameter 6: 15
•Press UP or DOWN to scroll to view the parameter.	<b>!5</b>	Safety Sens - Normal New Value? 15
•Press UP or DOWN to scroll to view the parameter.	<b>P.7</b>	Safety Sens - Reduced Parameter 7: 15
•Press UP or DOWN to scroll to view the parameter.	<b>P.8</b>	Safety Sens - Qpt Parameter 8: 15

### 23. PARAMETER CHART 3

#### Normal Speed Dwell

Parameter 12  
Sets the time in seconds

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

**P. 12**

**50**

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

**P. 13**

**25**

#### Accessing parameters from the main control panel.

- Press UP or DOWN to scroll
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

**Normal Speed Dwell Parameter 12: 50**

**Normal Speed Dwell New value?**

**SET UP DOWN RESET**

#### Accessing parameters from the main control panel.

- Press UP or DOWN to scroll
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

**Reduced Speed Dwell Parameter 13: 25**

**Reduced Speed Dwell New value? 25**

**SET UP DOWN RESET**

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

**P. 14**

**60**

#### Accessing parameters from the main control panel.

- Press UP or DOWN to scroll
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

**StormSwitch Duration Parameter 14:60**

**StormSwitch Duration New value? 60**

**SET UP DOWN RESET**

#### Accessing parameters from the main control panel.

- Press UP or DOWN to scroll
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

**Storm Switch Duration Parameter 14:60**

**Storm Switch Duration New value? 60**

**SET UP DOWN RESET**

## 24. PARAMETER CHART 4

### Idle Mode Timeout

Parameter 15 sets the amount of time the door remains at rest after the number of consecutive safety stops has been exceeded in parameter 24. This parameter is in 1/10 sec intervals ( $35 = 3.5$  sec)

#### Accessing parameters from the infrared control.

15

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

#### Park-N-Lock Dwell

Parameter 16 sets the amount of time (in seconds) the door will run in slow speed and annunciate before locking when mode 0 is activated. This parameter is used only if a brake is installed.

#### Accessing parameters from the infrared control.

16

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

#### Help Switch Timeout

Parameter 18 sets the length of time (in seconds) that the Help switches, mounted inside the drum, will re-activate the Park-N-Lock sequence. Once this timer expires, the door ignores the switch.

#### Accessing parameters from the infrared control.

17

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

#### Accessing parameters from the main control panel.

15

- |                                   |   |
|-----------------------------------|---|
| Idle Mode Timeout Parameter 15:35 | •Press UP or DOWN to scroll             |
| <b>35</b>                         | SET UP DOWN RESET                       |
| Idle Mode Timeout New value? 35   | •Press SET to view the parameter.       |
|                                   | SET UP DOWN RESET                       |
|                                   | •Press UP or DOWN to change the setting |
|                                   | SET UP DOWN RESET                       |

- All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.

#### Accessing parameters from the main control panel.

16

- |                                    |   |
|------------------------------------|---|
| Park n lock dwell Parameter 16: 30 | •Press UP or DOWN to scroll             |
| <b>30</b>                          | SET UP DOWN RESET                       |
| Park n lock dwell New value?       | •Press SET to view the parameter.       |
|                                    | SET UP DOWN RESET                       |
|                                    | •Press UP or DOWN to change the setting |
|                                    | SET UP DOWN RESET                       |

- All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.

#### Accessing parameters from the main control panel.

17

- |                                      |   |
|--------------------------------------|---|
| Help Switch Timeout Parameter 17: 60 | •Press UP or DOWN to scroll             |
| <b>60</b>                            | SET UP DOWN RESET                       |
| Help Switch Timeout New value? 60    | •Press SET to view the parameter.       |
|                                      | SET UP DOWN RESET                       |
|                                      | •Press UP or DOWN to change the setting |
|                                      | SET UP DOWN RESET                       |

- All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.

## 25. PARAMETER CHART 5

### Reserved time

Parameter 19 thru 22 are reserved time delays for future use. These values are currently ignored by the software.

#### Accessing parameters from the infrared control.

- 18 Thru 22
- Press "+" up "-" down or the number keys to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down or the number keys to change the value

#### Accessing parameters from the main control panel.

Reserved time Parameter 19, 10	•Press UP or DOWN to scroll
Reserved time New Value? 10	•Press SET to view the parameter.
All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.	•Press UP or DOWN to change the setting

- Sets the number of times that the door warns of a speed increase. This is in addition to the reduced speed switch cycle which always issues a warning.
- #### Accessing parameters from the infrared control.

- 23
- Press "+" up "-" down or the number keys to locate the desired parameter
  - Press "?" to view the parameter

#### Accessing parameters from the main control panel.

Speedup Warnings Parameter 23, 0	•Press UP or DOWN to scroll
Speedup Warnings New value ? 0	•Press SET to view the parameter.
All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.	•Press UP or DOWN to change the setting

#### Accessing parameters from the main control panel.

- Parameter 24 sets the number of safety stops that must be encountered before the door switches to "idle" mode.
- With the default value of 1 in use, the first motor overcurrent or nosing encountered places the door in the idle mode.
  - If a value of 2 is used, the first safety stop will stop the door for the duration of the time set in parameter 11. After this timer expires, the door will attempt to move forward again. A second motor overcurrent or nosing will place door in idle mode.
  - If idle operation is never desired, parameter 24 may be set to a very high value such as 100.
  - The safety stop counter is reset at every reference point.

#### Accessing parameters from the infrared control.

- 24
- Press "+" up "-" down or the number keys to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down or the number keys to change the value

#### Accessing parameters from the main control panel.

Safety Stops to Idle Parameter 24, 1	•Press UP or DOWN to scroll
Safety Stops to Idle New value ? 1	•Press SET to view the parameter.
All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0 seconds. A setting of 20 = 2.0 seconds.	•Press UP or DOWN to change the setting



## 27. PARAMETER CHART 7

### Relay K2 (38), K3 (39) & K4 (40) mapping

Parameters 38, 39 and 40 set the function of relays K2, K3 and K4 on the motherboard.

#### Accessing parameters from the infrared control.

- 38 •Press "+" up "-" down or the number keys to locate the desired parameter
- 39 •Press "?" to view the parameter
- 40 •Press "+" up "-" down or the number keys to change the value

- P.38 •Relay K2 mapping Parameter 38: 0
- P.39 •Relay K2 mapping New Value? 0
- P.40 •Relay K2 mapping Parameter 39: 0
- P.41 •Relay K4 mapping Parameter 40: 11

When set to the following values, each relay may be used to perform either of the following functions.

- 0 Relay disabled - no function
- 11 Power fail (line, internal DC)

When mapped to function 11, the relay doubles as a power failure detection contact, since the relay will be held on whenever the door is secured.

#### Reserved

Parameter 41 is reserved for use in future software

#### Accessing parameters from the infrared control.

- 41 •Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

#### Accessing parameters from the main control panel.

- P.38 •Press UP or DOWN to scroll Parameter 38: 0
- P.39 •Press SET UP DOWN to view the parameter. New Value? 0
- P.40 •Press UP or DOWN to change the setting Parameter 39: 0
- P.41 •Press UP or DOWN to change the setting Parameter 40: 11

#### Accessing parameters from the main control panel.

- P.38 •Press UP or DOWN to scroll Parameter 38: 0
- P.39 •Press SET UP DOWN to view the parameter. New Value? 0
- P.40 •Press UP or DOWN to change the setting Parameter 39: 0
- P.41 •Press UP or DOWN to change the setting Parameter 40: 11

## 28. PARAMETER CHART 8

### Remote Mode (Hardwired) (42) mode A / (43) mode B

- Parameters 42 and 43 are only active if parameter 60, Remote Mode (hard wired) select, is turned on.
- When remote mode select is in use:
  - Remote mode A selects the door mode to use when Aux A input is not active (terminals 3 & 4 of connector CN5 are open).
  - Remote mode B selects the door mode to use when Aux A input is active (terminals 3 & 4 of connector CN5 are shorted together)
  - Parameters 42 and 43 and 60 are used when the door mode is remotely controlled by a building management system.
  - If Parameter 60, remote mode select, is not in use the door mode is set with the LCP and parameters 42 and 43 are meaningless.
  - The keyswitch can not change the mode when remote mode select is in use.

### Accessing parameters from the infrared control.

#### 42 Accessing parameters from the main control panel.

- P.42**
- Press "+" up "-" down or the number keys to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down or the number keys to change the value
- P.43**

### Reserved

Parameters 44 through 59 are reserved for use in future software

### Accessing parameters from the infrared control.

#### 43 Accessing parameters from the main control panel.

- P.43**
- Press "+" up "-" down or the number keys to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down or the number keys to change the value
- P.59**

### Reserved

No remote file received during this time period.  
File was not received at all.

Windows has detected that file is missing or damaged.  
(This message will appear when the system has failed to receive a file or a corrupted file has been received.)

Windows has detected that file is missing or damaged.  
File was not received at all.

Windows has detected that file is missing or damaged.  
File was not received at all.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

Windows has detected that file is missing or damaged.

## 29. PARAMETER CHART 9

### Remote Mode Select

Parameter 60 determines whether the door's operating mode is set locally by the keyswitch (LCP) or remotely by a building management system.  
(See remote mode A, parameter 42, for additional information).

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down to change the value

#### Push-N-Go

When parameter 61 is turned on, the door will start if manually pushed for 2 or 3 inches. This is helpful in situations where pedestrains may be able to avoid the motion detector zone when entering or exiting.

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down to change the value


#### Shaft Brake Installed

When parameter 62 is turned on, the door will lock in place after Park-n-Lock feature has expired in mode 0.


#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down to change the value


#### Accessing parameters from the main control panel.



#### Accessing parameters from the main control panel.



#### Accessing parameters from the main control panel.



### 30. PARAMETER CHART 10


Storm Switch Only

**Storm Switch Only** If parameters 63 is off, Storm Lock will activate by turning the key switch to the left and holding. Applies to Grand™ doors where storm lock magnets are installed.

## Accessing parameters from the infrared control

- Press "+" up "-" down to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down to change the value

## **Accessing parameters from the main control panel.**




**Reserved** Parameters 64 through 91 are reserved for use in future software  
**Accessing parameters from the infrared control**

- Press "+" up "-" down to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down to change the value


תוֹרַת־בְּנֵי־יִשְׂרָאֵל

- This parameter is on the control panel.
  - Accessing parameters from the control panel:
    - Press "+" up "-" down to locate the desired parameter
    - Press "?" to view the parameter
    - Press "+" up "-" down to change the value

## Assessing parameters from the infrared central




## Accessing parameters from the infrared control



Reserved

Parameter 93 is reserved for use in future software

21



2

- Press "+" up "-" down to locate the desired parameter
  - Press "?" to view the parameter
  - Press "+" up "-" down to locate the desired parameter

## 31.PARAMETER CHART 11

### Wing sensors 3 thru 8

If any of the parameters (94 thru 99) are turned off the door will stop when contact is made with that sensor. If they are turned on the door will slow.

#### Accessing parameters from the infrared control.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "?" to view the parameter
- Press "+" up "-" down or the number keys to change the value

**P.94**

**OFF**

**P.95**

**P.94**

**OFF**

**P.95**

**P.94**

**OFF**

**P.94**


**OFF**

**P.94**

**OFF**

Parameter  
Sensor

- 94 = 3
- 95 = 4
- 96 = 5
- 97 = 6
- 98 = 7
- 99 = 8



Sensor locations

NOTE:  
•Sensor 3 will be the innermost sensor on each wing  
•Wing sensors 1(toe guard) & 2(wing breakout switch)  
will always stop the door when activated.  
•Different door diameters will have different numbers  
of sensors.

H916.33

#### Accessing parameters from the main control panel.

- Press UP or DOWN to scroll Parameter 94: Off
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

**SET**


**UP** **DOWN**

**SET**

**UP** **DOWN**

**SET**

**UP** **DOWN**



NOTE:  
•Sensor 3 will be the innermost sensor on each wing  
•Wing sensors 1(toe guard) & 2(wing breakout switch)  
will always stop the door when activated.  
•Different door diameters will have different numbers  
of sensors.

## 32. PARAMETER QUICK REFERENCE CHART

H916.34

PARAMETER	FUNCTION	DEFAULT	Comments	SECTION
1	Speed - Normal	60	The selected value = the motor voltage (see diagnostics 2 for run speed)	21
2	Speed - Reduced	40		21
3	Speed Qpt.	40		21
4	Reserved	0		21
5	Reserved	0	Sensitivity of the door's safety circuit to obstructions	22
6	Safety sens - Normal	15		22
7	Safety sens - Reduced	15		22
8	Safety sens - Qpt	15		22
9	Safety sens - Reserved	15		22
10	Safety sens - Startup	4		22
11	Safety stop time	35	Measured in 1/10 seconds	23
12	Normal speed dwell	50	Measured in seconds	23
13	Reduced speed dwell	25	Measured in seconds	23
14	Storm switch duration	60	Measured in minutes	23
15	Idle mode time out	35	Measured in 1/10 seconds	23
16	Park-n-lock dwell	30	The time the door turns in slow speed and announces before locking in mode 0 (in sec)	24
17	Help sw time out	60	The amount of time after lockup when the door can be re-started by the help switch (in sec)	24
18	Reserved	10		24
19	Reserved	10		25
20	Thru	↑		25
21	Reserved	10		25
22	Speed up warning	0	Number of warnings door will when changing from reduced speed to normal speed	25
23	Safety stops to idle	1	The number of stops allowed before Idle Mode is active	25
24	Entry Guard Offset	15	Determines the entry guard zone size	26
25	Reserved	1		26
26	Reserved	1		26
27	Network Address	0	Address of door in building mgmt. network	26
28	Reserved	0		26
29	Thru	↑		27
30	Reserved	0		27
31	Relay K2 mapping	0	Sets individual relay output signals (Limited selection in this control)	27
32	Relay K3 mapping	0		27
33	Relay K4 mapping	1		27
34	Reserved	0		27
35	Remote mode A	0	Parameter 60 must be turned on - Sets mode with Remote switch open	28
36	Remote mode B	1	Parameter 60 must be turned on - Sets mode with Remote switch closed	28
37	Reserved	↑		28
38	Relay K2 mapping	0		28
39	Relay K3 mapping	0		28
40	Relay K4 mapping	1		28
41	Reserved	0		28
42	Remote mode A	0		28
43	Remote mode B	1		28
44	Reserved	No		28
45	Thru	↑		28
46	Reserved	No	When turned on, the door is controlled by the Aux A CN5 input - See parameter 42 & 43	29
47	Remote mode select	Off	Determines whether the door can be manually pushed to start	29
48	Push-N-Go	On	Turn On if brake is installed	29
49	Core brake installed	Off	Off - Storm Lock On - Storm Switch	29
50	Storm switch only	Off		30
51	Reserved	Off		30
52	Thru	↑		30
53	Reserved	Off		31
54	Parallel core wiring	Off	Off - Ignores 6008 card	31
55	Reserved	Off	On - looks for sensor signals - 1 stop - 1 slow	31
56	Wing sensor 3 slows	4 slows		31
57		5 slows		31
58		6 slows		31
59		7 slows		31
60		8 slows		31
61		Off		31
62		Off		31
63		Off		31
64		Off		31
65		Off		31
66		Off		31
67		Off		31
68		Off		31
69		Off		31
70		Off		31
71		Off		31
72		Off		31
73		Off		31
74		Off		31
75		Off		31
76		Off		31
77		Off		31
78		Off		31
79		Off		31
80		Off		31
81		Off		31
82		Off		31
83		Off		31
84		Off		31
85		Off		31
86		Off		31
87		Off		31
88		Off		31
89		Off		31
90		Off		31
91		Off		31
92		Off		31
93		Off		31
94		Off		31
95		Off		31
96		Off		31
97		Off		31
98		Off		31
99		Off		31

### 33. DIAGNOSTICS QUICK REFERENCE CHART

DIAG	FUNCTION	Comments	SECTION
1	Check power supply	Displays DCV output of the power supply to operate the motor & brake	13
2	Check door speed	LCP displays door speed, MCP displays motor voltage & RPM	13
3	Check motor current	LCP displays motor current, MCP displays motor current & voltage	14
4	Check brake voltage	LCP displays brake voltage, MCP displays brake current & voltage	14
5	Check brake current	LCP displays brake current, MCP displays brake current & voltage	14
6	Encoder test	LCP and MCP display encoder count in each quadrant	14
7	Check inputs	LCP displays codes of active inputs, MCP displays text of active inputs	15
8	Play / set up voices	Displays low voltage DC value	16
9	Check 24 V supply	Reserved for future use	16
10	Reserved	Reserved for future use	17
11			17
12			17
13	Reserved	Reserved for future use	17
14	Find safety sensors	Finds the door wing sensors and programs the software to respond to them	17
15	Learn safety limits	Sets the safety limits by current sensing	17
16	Complete setup	Restores factory default settings to all parameters	18

### 34. ERROR CODES


All errors except 7 are considered major and require a keyswitch reset to clear them and restart the door.

LCP  
display


- Er 3 Motor current excessive - only occurs during setup phase
- Er 4 No reference switch - only occurs during setup phase
- Er 5 Encoder phasing incorrect - only occurs during setup phase
- Er 6 No encoder pulses received - only occurs during setup phase
- Er 7 Brake failure - A run time error that is displayed if insufficient brake voltage and / or current are detected when the door is supposed to be secure. It is self-clearing when proper voltage is restored.
- Er 8 High voltage DC failure
- Er 9 Drive system failure

### **35. CONNECTING SENSORS TO THE 9150 CONTROL FOR AUTOMATIC DOORS**

H916.36



## 36. CONNECTING SENSORS TO THE 9150 CONTROL FOR GRAND DOORS



**Horton Automatics, U.S.A.**

Tel: 800-531-3111, Fax: 800-531-3108

Internet: <http://www.hortondoors.com>

**Horton Automatics, Ltd.**

Tel: 01952 670169, Fax: 0192 670181

A Division of Overhead Door Corporation, A Sanwa Shutter Company

International Tel: ++44-1952-670169

International Fax: ++44-1952-670181