

besam

information bulletin

BESAM INC. ■ 81 TWIN RIVERS DRIVE ■ HIGHTSTOWN, NJ 08520-5212
(609) 443-5800 ■ FAX (609) 443-9162 443-5629

#273


JULY 1998

READY-FOLD UPDATE


The Ready-Fold door has been designed so that the *Slide Block* (series 200 doors) and *Roller* (Ready-Fold 400) are interchangeable. While the slide block will continue to be the standard offering, certain field conditions may warrant the use of a roller instead. The door can be ordered with a roller simply by specifying your preference on the order form. If desired, the slide block can also be field changed to a roller. By the same token, a slide block kit is available for those who wish to change their older Ready-Fold from rollers to slide blocks.

Available Parts:


Carrier Roller Kit:
P/N 55-15-015s
(to replace existing
rollers or slide blocks).



Slide Block Kit:
P/N 55-15-201s
(to retrofit Ready-Fold 400 doors*)




Slide Block:
P/N 55-15-345s
(replacement for
Series 200 doors*)



***Note:** Ready-Fold 400 doors use a continuous hinge, Ready-Fold Series 200 doors use separate top and bottom hinges.

[REMEMBER ENGINEERING DEPT. FAX # (609) 443-5629]

Naturally, to make sure this equipment continues to function properly for years to come, you will want to purchase only Replacement Parts that are designed to function with the original equipment. Genuine Replacement Parts from Besam are the finest parts money can buy. We do not cut corners. They are manufactured to exacting specifications and are not just designed to 'fit' -- they are made to function just as the original components. Genuine Besam Replacement Parts have been tested to ensure that they perform properly and reliably. Genuine Besam Replacement Parts are only available through an authorized Besam distributor.




Ready-Fold 400 SPARE PARTS LIST WITH SWINGMASTER 405


[illegible]




55-15-040 Arm, OHC




55-03-055 Spring, Torsion, RH (Shown)
55-03-*056 Spring, Torsion, LH



55-15-005 Panic, Clapper Assembly, Door Portion




50-04-203 Panic Assembly, Gear Only



55-02-025 Control, Eye-Cue + LTO Board
Assembly + RAI



55-15-004 Panic Catch Assembly, Magnetic



50-15-417 Panic Ball Catch Assembly, Clear
50-15-416 Panic Ball Catch Assembly, Bronze



55-15-001 Pivot Assembly, Top RH
55-15-002 Pivot Assembly, Top LH

Phone: (866)237-2687
Fax: (609)443-3438


2003

parts@besam-usa.com
rebuilding@besam-usa.com


55-15-015 Roller Kit, Carrier




Upper Hinge Assembly, Out Fold LH
REFERENCE ONLY



55-15-120 Bearing Pivot, Carrier



55-15-122 Bearing Pivot, Single




Phone: (866)237-2687
Fax: (609)443-3438


2003

parts@besam-usa.com
rebuilding@besam-usa.com


55-03-040 Shaft, Long




55-15-121 Bearing Pivot, Double




Upper Hinge Assembly, Out Fold RH
REFERENCE ONLY




55-15-070 Switch, Key Clear Momentary
55-15-071 Switch, Key Bronze Momentary






RH

Upper Hinge Assembly, In Fold RH
REFERENCE ONLY




LH


Upper Hinge Assembly, In Fold LH
REFERENCE ONLY



55-09-045 Washer, Thrust



55-15-120 Bearing Pivot, Single



55-15-121 Bearing Pivot, Double







55-15-345 Guide, Kick off Assembly (Top of
screw not included)



55-03-042 Insert







55-03-017 Slide Block Screw




Phone: (866)237-2687
Fax: (609)443-3438

2003



parts@besam-usa.com
rebuilding@besam-usa.com



55-15-403 Guide Track Kit Prep LH (Specify Color, Black or Clear & Size)

5515-402 Guide Track Kit Prep RH (Specify Color, Black or Clear & Size)