



DETAIL 1

NOTES:

NEVER install this product on a manually operated door without a supplemental detector! Refer to instructions for additional details.

Orange wire from CN2 MUST be connected to control wire which is positive (+) when door is opening.

White wire from CN2 MUST be connected to motor wire which is positive (+) when door is opening.

NEVER reverse orange and white wires.

The C04150.0002 MUST be the last device before the motor.

Input 2 and Input 3 may be used for a variety of functions. Refer to Installation instructions for details.

* May be connected to separate power supply if necessary.

Actuate and Lock outputs rated 3A, 32vdc maximum.

T-Stop should be disabled by removing JB2 Jumper.

This document contains Horton Automatics proprietary information and may not be reproduced, disclosed or utilized in whole or in part without written authorization.

NO.	REV. DATE	DRAWN BY	CHECKED BY	ECO#
0	1/6/15	JD	BB	
1				
2				
3				
4				

.XXXX ± .0005 .XXX ± .005 .XX ± .01 .X ± .1 FRACTIONAL ± 1/32" ANGLES ± 1/2°	QUALITY AUDIT
	REVISION
MATERIAL:	
FINISH:	
SCALE: DO NOT SCALE	
DESC: C04150.0002 WIRING DIAGRAM	

4242 Baldwin Boulevard
Corpus Christi, Texas 78405
(800)531-3111
<http://hortondoors.com>

FACTOR:

MULTIPLIER:

PART NO. **C4150-2**

0