ED400 Surface Applied



AUTOMATIC SWING DOOR SURFACE APPLIED (SA) INSTALLATION INSTRUCTIONS

Distributed by:

ſ		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı	1	
ı		
ı		
ı	1	
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı		
ı	1	
ı	1	
ı	1	
ı	1	
ı	1	
ı		
ı		
ı	1	
ı	1	
ı		
ı	1	

DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999



Important Installation Instructions

ALL INSTALLATIONS AND SERVICE SHOULD ONLY BE PERFORMED BY TRAINED OR AUTHORIZED PERSONS

Warning - To reduce the risk of injury or death:

- 1. Carefully Read And Follow All Installation Instructions
- 2. This unit should only be installed in a rough opening capable of providing proper structural support.
- 3. Always disconnect the power supply before servicing.
- 4. To install and adjust the door for proper and safe operation, the installer must carefully read and follow these instructions exactly.
- 5. The door is designed to be installed only by trained and knowledgeable installers. The installation technician should be experienced in the installation of automatic entrances. They should know all local code requirements and be familiar with the requirements of the current ANSI A156.10 & 156.19 Standards for Power Operated Pedestrian Doors.
- 6. After installation, the door must be adjusted to conform with DORMA recommendations and all code requirements. Carefully study the requirements in these instructions.
- 7. After installation and adjustment, the installers final responsibility is to properly instruct the owner in the safe use of the door. He must also present the owner with the ED400 Owner's Manual and carefully explain how to perform the daily safety check test.
- 8. Each step of the installation, adjustment and instructions are important for proper and safe use of the door being installed. If there are any questions about any items contained in these instructions, call the DORMA Technical Assistance Group for assistance.
- 9. Save these instructions for future reference.

Compliance with Safety Standards

Your door system was designed to the latest operating and safety standards. In order to ensure the continued safe operation of your door, it is important that:

- Your door system be maintained in compliance with the standards of the industry, BHMA/ANSI 156.10 or 156.19.
- Proper decals and labels be applied, per BHMA/ANSI standards, and maintained on your doors. If decals are removed, or cannot be read, request labels to be replaced when calling for service.

Toll-Free: 877-367-6211

Fax: 877-423-7999

DORMA AUTOMATICS, Inc. 924 Sherwood Drive Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com

ED400 Surface Applied



Tools Required:

Screwdrivers

Small Straight (Flat Blade) - for Terminal Block wiring #2 Phillips (Crosspoint) - for various #8, #10, and #14 screws

Wrenches / Sockets

7/16" - for #1/4-20 Hex Head bolts attaching header to jambs 9/16" - for adjustments of hardstops (2 wrenches needed)

Allen Wrenches

1/4" - for top and bottom pivot

Electric Drill with the following drill bits -

3/8" - for attaching rivenuts to jambs

9/64"(or #28) - for installing sensors

5/32" (or #22) - for installing #10 sheet metal screws into adjacent storefront & Bottom pivot

13/64" (or #7) - for installing #14 sheet metal screws into adjacent storefront 1/4" - for clearance holes in jambs

Impact Drill with the following masonry bits -

1/4" - for #10 screw anchors 5/16" - for #14 screw anchors

Level - suggested 4' minimum
Step Ladder - 4' or 6'
Tape Measure
Rubber mallet or Hammer - for arm attachment
Caulking and Application Gun
Electrical Wire Strippers / Cutters - for sensor wiring

Suggested Fasteners Required - (Not supplied)

Jamb Attachment Screws -#14 X 2-1/2" PHSMS (Pocket Jambs) #14 X 3" FHSMS (Tube Jambs) Optional Anchors for masonry

Threshold Attachment Screws #10 X 1-1/2" FHSMS Optional Anchors for masonry

Header Attachment Screws #14 X 1-1/2" HHSMS #14 Flat Washer

Construction Shims - for squaring door frame in opening

Toll-Free: 877-367-6211
Fax: 877-423-7999

Subject to change without notice



Contents

SA (Surface Applied)

Section A:	pg. 4-6	Mount the door frame, operator, and controller.
Section B:	pg. 7-10	Controller Connections and Install sensors.
Section C:	pg. 11	Power the Operator to Hardstop
Section D:	pg. 12-14	Mounting of Push Arm. Hardstop Adjustment. (optional)
Section E:	pg. 15-18	Mounting of Pull Arm. Hardstop Adjustment. (optional)
Section F:	pg. 19-20	Basic Set-Up
Section G:	pg. 21	Customize Set-Up
Section H:	pg. 22-23	Setting up Simultaneous Doors (side-by-side)
Section I:	pg. 23	Setting up Semi-Independent Doors (side-by-side)
Section J:	pg. 24	Magnetic Locks
Section K:	pg. 24	Final Check
Section L:	pg. 25-26	Technical Data


DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999



Section A: Mount the operator





DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044


E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999






Section A: Mount the operator







DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044


E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999






Section A: Mount the operator








DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999



Section B: Connecting the Controller and Sensors



DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999

DL2609-010 AUG. 2006 Subject to change without notice В



Section B: Connecting the Controller and Sensors (BEA)




DORMA AUTOMATICS, Inc. 924 Sherwood Drive Toll-Free: 877-367-6211 DL2609-010 Lake Bluff, IL 60044 Fax: 877-423-7999 AUG. 2006

E-mail: automatics@dorma-usa.com



Section B: Connecting the Controller and Sensors (Bircher Reglomat)



DORMAAUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044


E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999


DL2609-010 AUG. 2006




Section B: Connecting the Controller and Sensors









DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999

DL2609-010 AUG. 2006 Subject to change without notice 3




Section C: Power the Operator to Hardstop

The purpose of this feature is to drive the operator to the fully-open hardstop. It is also used to load the operator spring during the installation.


Basic Requirements

- · All cables are connected.
- Swing area is clear of obstacles
- Mode switch in position "OFF".
- Controller must have "Low Energy Switch" in "OFF" position.
- Power connected.

Start-Up



- The display will read "ALL".-
- Turn mode switch from "OFF" to the "ON" position.




- The operator pinion will now begin turning slowly in the open direction, and stop indefinitely at the hardstop.
- Connect the arm to the operator pinion with the door opened to the desired fully open position.
- When installation procedure is complete, turn the mode switch to the "OFF" position to power down the operator and close the door.



924 Sherwood Drive Toll-Free: 877-367-6211 Lake Bluff, IL 60044 Fax: 877-423-7999 E-mail: automatics@dorma-usa.com



Section D: Mount the Push Arm




DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999



Section D: Mount the Push Arm







DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044


E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999



Section D: Mount the Push Arm





- (1) Electronic Stop this is set by the controller and acts as the backstop during door operation. It is always set at less than the angle for the Physical Hardstop. Set around 3° to 5° less than the Physical Hardstop.
- 2) Physical Hardstop this is set physically as specified above in Figure 17a. In the event of a forced collision, this would set the maximum opening angle of the door; typically 95° for a 90° opening.

Toll-Free: 877-367-6211

Fax: 877-423-7999


924 Sherwood Drive DORMA AUTOMATICS, Inc. Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com

DL2609-010 AUG. 2006



Section E: Mount the Pull Arm (For 0" Reveals)



DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999

15 DL2609-010 AUG. 2006 Subject to change without notice Е



Section E: Mount the Pull Arm (For Reveals up to 6")



DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999


16 DL2609-010 AUG. 2006 Subject to change without notice Е



Section E: Mount the Pull Arm








DORMA AUTOMATICS, Inc.


924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999



Section E: Mount the Pull Arm





- 1 Electronic Stop this is set by the controller and acts as the backstop during door operation. It is always set at less than the angle for the Physical Hardstop. Set around 3° to 5° less than the Physical Hardstop.
- 2 Physical Hardstop this is set physically as specified above in Figure 23a. In the event of a forced collision, this would set the maximum opening angle of the door; typically 95° for a 90° opening.

Е

DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com



Section F: Basic Set-Up

The purpose of the initial setup is to bring the ED400 to a point where it can open the door. If the door panel is to be mounted, please refer to Section B.


Preparation for Initial setup

Basic Requirements

- All cables are connected.
- Swing area is clear of obstacles
- Mode switch in position "OFF".
- Controller must have "Low Energy Switch" in "OFF" position.
- Power connected.


Start-Up

Turn selector knob to "TYPE".




Turn dial knob to select "Low Energy", "Power Assist", or "Full Power". The corresponding 3 letter codes are "LE", "PA", and "FUP".

The example above shows "Full Power". NOTE: for "Low Energy" operation, turn the Low Energy swith to "ON".




Turn selector knob to "MOUNT".



Turn dial knob to select Push Mount "PSH" or Pull Mount "PUL".

DORMA AUTOMATICS, Inc. 924 Sherwood Drive Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com




CLS SPD

Turn selector knob to "BCK STP"


Turn dial knob so that display shows "90". This is your back stop in degrees.

NOTE: If the door is to be set to an angle other than 90° measure the angle the door will open to and input that value in the step above.


Turn selector knob to "LEARN".



- Turn dial knob so that display shows "ALL". This will cause a full learn cycle.
- Turn mode switch from "OFF" to the "ON" position.



The controll box display will show "ALL", indicating that a learn cycle is in progress.



The door will stay closed for 10 seconds to let you get into position to catch it at the desired Back Stop.

Toll-Free: 877-367-6211

Fax: 877-423-7999

19 DI 2609-010 AUG. 2006



Section F: Basic Set-Up

 The door will begin to open slowly. Stop the door at the desired Back Stop position until it begins to close back to latch position.




Please let the door close. Stand clear. Let go of the door and MOVE OUT OF THE WAY!



The door will now SLAM open to 45, to measure it's inertia.



 When the controller has learned all of it's selfadjustments, the display will show "rdY".



 The door will now cycle open and close continuously. The door has reduced obstacle detection, DO NOT INTERFERE WITH DOOR!




 If you are satisfied with the door's operation, turn the mode switch to the "OFF" position and allow the door to close completely.



NOTE: If door motion is undesireable or if adjustments need to be made to meet ANSI guidelines, refer to Section G to make additional changes (Open Speed, Back Check angle, Deceleration, Close Delay, CLosing Speed, etc.)





The display will show the present state of the opener.

CODE		STATES	DESCRIPTION	
C	C L d ClosedO P n OpeningP. A. Power AssistO P d Opened		Closed	Door is at Latch-Stop
0			Opening	Opener is opening to Back-Stop
Ρ.				User may open door with opener's assistance
0			Opened	Opener is holding door at Back-Stop
C	Ш	r	Closer	Acts as a passive closer, letting user open door manually, closing the door
С.	0	р	Closing Obstacle	Opener reacted to obstacle during closing cycle
0.	0	b	Open Obstacle	Opener reacted to obstacle during opening cycle
Α		L	Learning	Opener is learning
C	у	C	Cycle	Opener is going through a learning cycle
r	S	t	Reset	Opener is being reset

NOTE: If there is an exception to it's operation, it will show a code for it. If an exception code is displayed, see ED400 Controller Manual for an explanation.

- Test the opener's operation with the sensors.
- Test that the door meets ANSI standards.

Toll-Free: 877-367-6211

Fax: 877-423-7999

 FOR ADDITIONAL SET-UP OPTIONS, SEE THE ED400 CONTROLLER MANUAL. (www.dorma-usa.com)

The door is now ready for normal operation.

Н

DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com

DL2609-010 AUG. 2006 without notice



Section G: Customized Set-Up

The purpose of the customized set-up is to change the default ED400 settings. This can be done during or after a completed learn cycle.

Parameters

- Open speed to Back-Check
- Back-Check angle
- Deceleration through Back-Check
- Back-Stop angle
- Close Delay
- Closing speed to Latch-Check
- Latch-Check angle
- Closing speed through Latch-Check
- Using the example to the right, and the table below, make parameter changes as desired. When finished, return the selector knob to "RUN", or do another "LEARN" Cycle if the door's motion has been poorly affected.
- For further Set-Up options contained in "MONITOR", "MON SEL", "MISC ADJ", and "MISC SEL", please consult the ED400 Controller Manual. It can be found at the DORMA website: www.dorma-usa.com .

Open Speed to Back-Check (example) Turn selector knob to "OPN SPD". -

The display will show the code and the value. RUN TYPE -- Mount **LEARN** MONITOR

MON SEL-MISC ADJ

MISC SEL

LCH-CHK

CLS SPD

Turn the dial knob to select the desired speed in DEGREES/SECOND.

BCK-CHK =BCK SPD BCK STP

HOLD OPN DLY



Selector	Code Meaning	"Dial" Knob Function	DISPLAY	UNITS
OPN SPD	Open Speed	increment/decrement	Opening speed to Back-Check	°/s
BCK-CHK	Back-Check	increment/decrement	Back-Check angle	0
BCK SPD	Back-Speed	increment/decrement	Opening speed to Back-Stop, or Off	°/s
BCK STP	Back-Stop	increment/decrement	Back-Stop angle	0
HOLD OPN DLY	Hold Open Delay	increment/decrement	Time at Back-Stop	S
CLS SPD	Close Speed	increment/decrement	Max closing speed to Latch-Check	°/s
LCH-CHK	Latch-Check	increment/decrement	Latch-Check angle	0

RESETTING THE CONTROLLER

To RESET the controller, turn the selector knob to "MISC SEL" and turn the dial knob until "rst" is displayed. Now turn the selector knob to "MISC ADJ", and turn the dial knob from "ON", ONE click clockwise to "OFF". The controller has now been reset.

DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com

Toll-Free: 877-367-6211 Fax: 877-423-7999

21 DI 2609-010 AUG. 2006



Section H: Setting Up Simultaneous Doors


The purpose of the this setup is to synchronize two side-by-side doors for simultaneous operation. This operator is not compatible with over-rebated doors.

Connecting the Controllers

- · Connect the grounds of the two controllers together.
- Connect the motion sensor to both controllers in parallel.
- Connect the presence sensor to both controllers in parallel, except for the Data Line.
- Let each controller power it's presence sensors (either controller can power the motion sensor).
- Connect a single program switch to both doors in parallel.

- Connect the RXD line of each controller to the TXD line of the other controller.
- If you use the "Fire" input, connect the Fire sensor to both controllers.
- If you use the "Breatout" input, connect the Breakout switch to both controllers.
- Connect both controllers to the same AC power source.
- Program the two controllers identically (Refer to Sections F and G).

(Continued on following page)





DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com


Toll-Free: 877-367-6211 Fax: 877-423-7999



Section H: Setting Up Simultaneous Doors

Run a "Learn" cycle on both controllers. It's easier if they are done seperately.

If it's desired that the doors open and/or close differently, continue on this side of the page. If not, skip to the top of the column to the right.



- Turn dial knob so that display shows "ALL". This will cause a full learn cycle.
- Open one of the doors and allow it to close. As it's closing, flip the program switch from "OFF" to "ON".



- The door that was closed will start a Learn Cycle, and the one that you opened will finish closing and then start a Learn Cycle. This will give you a chance to stop the first door at Back-Stop, and then walk to the second door and stop it at Back-Check when it gets there.
- When both openers are ready, trigger an automatic opening, and, as the doors are opening, block one of doors. Turn ON/OFF/HO switch to "OFF" position, then back to "ON"
- When they start moving again, block the other one. Turn ON/OFF/HO switch to "OFF" position, then back to "ON".

This will let each opener tell the other of having detected an obstacle, so that each will know of the presence of a second door. Knowing that, the openers will extend the Hold-Open time after an obstacle, to ensure that both doors remain in synchronization afterwards.


DORMA AUTOMATICS, Inc.

Section 1: Setting Up Semi-Independent Doors (Double Egress)

The purpose of the this setup is to synchronize two side-by-side doors for semi-independent operation. This means that the doors will open and close at the same time, but will react to obstacles independently.

Connecting the Controllers

- Program the two controllers identically (for coordinated doors - one must close first increase slightly the Closing Delay of the controller for the door that must close last)
- Connect the grounds of the two controllers together.
- Connect one door's presence sensor to the controller for that door.
- Connect the motion sensor to both controllers in parallel
- Let each controller power its presence sensors (either controller can power the motion sensor)
- Connect a single program switch to both controllers in parallel.
- Power the controllers from the same AC power source.



924 Sherwood Drive Lake Bluff, IL 60044 Toll-Free: 877-367-6211

Fax: 877-423-7999

E-mail: automatics@dorma-usa.com



Section J: Magnetic Locks


The purpose of the this section is to setup an electric lock. The controller may power an electric strike through a relay or access control device.

Connecting a Magnetic Lock

- If the installation has a 24 Vdc electric strike plate (electric lock), the controller is able to power it directly. (See Figure 1)
- For DC locks of other voltages, you will need a seperate power supply. (See Figure 2)
- For AC locks, you will need a seperate transformer and a relay. (See Figure 3)


- The "Open Delay" must be set per manufacturer's specification.
- The controller drives the electric lock from when it receives a valid trigger (at Latch-Stop), while waiting to open (because of a non-zero Open Delay, or because the swing area is occupied), and until some time after the door has begun to open. It also drives it if the door reaches Latch-Stop, as it is retriggered.
- The LOCK LED lights up while the controller drives an electric lock, whether or not a lock is actually present.

NOTE: For wiring locations on controller, see Section B, Figure 8.



Section K: Final check

- •Test all sensors along with door operation to ensure they are working properly.
- Provide safety list similar to that provided by AAADM.
- •Make sure that all electrical wiring is connected correctly and away from moving parts.





DORMA AUTOMATICS, Inc.

924 Sherwood Drive Lake Bluff, IL 60044

E-mail: automatics@dorma-usa.com

24 DL2609-010 AUG. 2006 Subject to change without notice

Toll-Free: 877-367-6211

Fax: 877-423-7999



Section L: Technical Data

Operator		
Line Input Power supply for external sensors Fuse Ambient Temperature	100 to 125V AC, 60 H 24 V DC, 0.8 A 2 A fast blow 77 °F(25 °C)	z, 2 A max.
Adjustments	min.	max.
Opening time to Back-Check Closing time to Latch-Check Delay beforeOpening Delay beforeClosing Back-Stop Angle Back-Check-Angle Latch-Check-Angle Wall-Mask-Angle Extra Power Hold Torque	2.0 s 2.5 s 0 s 1 s 60° 50° 10° 60° 40 ft-lb	7 s 7 s 3 s 25 s 120° 120° 30° 115° 240 ft-lb
Door	min.	max.
Door height Door weight Door mount - single Door width Door mount - pair Door width	84" 60 lbs (27 kg) SA (Surfaced Appl 37" SA (Surfaced Appl 62"	51"

			_
Control	lor	Technical	Data
(() ()	1-1	1 - (חומות

Power input			
Connector	2-piece	terminal block	
Line Input	100 to 125Vac, 60 Hz, 2 A max.		
Fuse	2 A, fast (5mm x 20mm)		
DC power out		800 mA out, always on,	
•		rcuit protected, not regulated	
Control inputs		, ,	
Connector	2-piece	terminal blocks	
Active low inputs	•		
		rigger (radar or push plate)	
	•	e, jamb mounted sensor	
		ide, door mounted sensor	
		ch Side, door mounted sensor	
	Hold-Op		
	Off		
	Safety B	Seam Sensor	
Polarity	-	active low or closed contact to	
-		ground	
Active threshold		< 0.8 Vdc	
Inactive threshol	d	> 2.0 Vdc	
Closed contact co	urrent	10 mA surge, 1 mA steady	
		state	
Open circuit volt	age	5 V	
ESD protection		±5 KV, human body model	
Overvoltage prot	ection	±5 Vdc or 5 Vac, continuous,	
		with respect to GND	
Smoke (Kill) link	input:		
Polarity		normally closed contact to	
		GND	
Closed contact c	urrent	2 mA	
ESD protection		±5 KV, human body model	
Overvoltage prot	ection	±5 Vdc continuous, with	
		respect to GND	

	70		
Termin	al Designations		
1-8	+24V		
9	Electric Strike		-Output
10	Data (Zone)		-Output
11	Trigger (radar or push plate)		-Input
12	Presence (jamb mounted sensor)		-Input
13	Safety Side (door mounted sensor)		-Input
14	Approach Side (door mounted sense	or)	-Input
15	Safety Beam	,	-Input
16	Kill (Śmoke) link		-Input
17-24	GND		•
Program	switch		
3	Hold Open	- Ir	nput
2	GND		
1	OFF	- Ir	nput
Breakou	t		
1	Breakout Switch	-(N	l.C.)
2	GND		
Motor			
1	M+		
2	M-		
Power Ir	nput		
1	Neut.		
2	Earth Ground		
3	Hot 100 to 125 VAC, 60 Hz, 2	Αm	nax.

Toll-Free: 877-367-6211

Fax: 877-423-7999

DORMA AUTOMATICS, Inc.

Indicators

924 Sherwood Drive Lake Bluff, IL 60044 E-mail: automatics@dorma-usa.com

1 LED/Sensor, 3-Digit Display



Section L: Technical Data

Operation Instructions

1. Program Switch



Switch is in position:



Continuous Open Operation The door opens to the full opening position and remains in this position.

OFF



When an activation signal is detected from the motion detector the door opens to the full opening position. After the hold open delay expires the door closeses.



The door stops immediately when the switch is placed in this position and closes slowly under springpower. The closing speed is limited. The user may open the door manually.

Restart after power failure When the power is turned ON, the ED400 goes back to normal operation.

2. Care and Maintenance

Prior to first use and periodically thereafter, but at least once a year, the system must be checked and maintained by a qualified, knowledgeable technician. During the cleaning operation the Program Switch must be either in the OFF or HOLD OPEN position to avoid automatic movements of the door wings. Always disconnect the appliance before servicing. The entire swing door assembly (Aluminum, Glass, Covers) can be cleaned with a moist towel and common commercial cleaners. The safety sensors are to be cleaned with a dry, soft, non-abrasive towel. The floor area near the swing door panel, including the threshold must be kept clean.

- 3. Self Help Troubleshooting of Problems If the door does not open or close, check the following:
 - Is the line power in order?
 - Is the Program Switch in the proper position?
 - Is the safety sensor path clear and clean?
 - Is the door blocked by obstacles?

If all of the above check out OK call a qualified Service Technician.

ED400 MUST BE SET UP WITHIN **BHMA/ANSI STANDARDS**



25

DI 2609-010 AUG. 2006 Subject to change without notice

Toll-Free: 877-367-6211

Fax: 877-423-7999